

BRACKET MOUNT 2 PC VISOR INSTRUCTION


1987+ FLAT TOP & ULTRACAB UNIVERSAL

NOTE : ALL VISORS SHOULD BE TEST FIT TO THE TRUCK BEFORE PAINT / INSTALLATION

Bracket # per Model


3018:	3019:	3021:	3053:	3059:	3060:
01*3ea	02*3ea	01*1ea	02*2ea	00*2ea	02*2ea
02*3ea	03*3ea	02*2ea	03*2ea	01*1ea	03*2ea
		03*2ea	04*1ea	02*1ea	04*1ea
		04*1ea	05*1ea	03*2ea	05*1ea

- 1 Remove factory visor and brackets.
- 2 Drill out factory holes to 1/2".
- 3 Install new brackets in factory locations.
- 4 Fasten visor to brackets.



A Center brackets will require additional holes for certain models.

B The outside brackets will not have factory holes. they will have to be drilled at the 9th rivet location



01-09003060
01-09003059
01-09003053

01-09003019
01-09003021
01-09003018

SAFETY WARNING & PRECAUTIONS

READ CAREFULLY AND UNDERSTAND ALL ASSEMBLY AND OPERATION INSTRUCTIONS BEFORE OPERATING. FAILURE TO FOLLOW THE SAFETY RULES AND OTHER BASIC SAFETY PRECAUTIONS MAY RESULT IN SERIOUS PERSONAL INJURY.

GENERAL SAFETY RULES



WARNING: Read and understand all instructions. Failure to follow all instructions listed below may result in serious injury.

CAUTION: Do not allow person to operate or assemble this Kit until they have read these Instructions and have developed a thorough understanding of how the Kit works.

WARNING: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors that cannot be built into this product, but must be supplied by the operator.

IMPROPER USE

Any use of the parts for purposes other than that intended is deemed improper. 4 State Trucks shall not be liable for damage to persons or property resulting from improper use.

PERSONAL PROTECTIVE EQUIPMENT

If required, wear personal protective equipment.

The personal protective equipment consists of

- safety footwear
- hard hat
- protective gloves
- hearing protection
- safety glasses

The personal protective equipment must be suitable for the pressurised medium.

4 State Trucks

4579 Highway 43, Joplin, MO 64804

Chrome & Accessories: 888-875-7787

Collision Parts: 855-220-8608

Fax: 417-624-2489

HOURS

8 AM - 5 PM (Mon - Fri)

9 AM - 3 PM (Sat)

Closed (Sun)

LIABILITY & WARRANTY

LIMITATIONS OF LIABILITY

To the extent allowed by local law, except for the obligations specifically set forth in this warranty statement, in no event shall the manufacturer and 4 State Trucks or its third party suppliers be liable for direct, indirect, special, incidental, or consequential damages.

WARRANTY

1 Year Limited Warranty

We warranty listed parts to be free from defects in material and workmanship for the period specified on your invoice. It begins from the date purchased. This warranty does not apply to parts unless the installation instructions are followed in their entirety. Air Ride Kit and Flip/Lift Bumper Kit Installation should be performed by a licensed mechanic.

LIMITATIONS OF WARRANTY

This warranty does not cover any expenses incurred in the removal and / or reinstallation of the part. Specifically, this warranty does not cover any expenses for time, or other parts not purchased from us, or any labour. This warranty covers fixing or replacing the part only. This warranty is offered only to the original purchaser of the part.

This warranty does not apply, and will be voided, if the part sold has been damaged by abuse, misuse, accident, neglect, modification, or alteration, or if it has been repaired or replaced by anyone other than us.

This warranty does not cover damages caused by the use of parts of different manufacturers.

Your warranty will be null and void if the part fails due to improper installation. If the part sold should prove defective in material or workmanship within the warranty period, return the part to us, along with your sales invoice. (Shipping/freight charge will not be covered by us.) Your dated invoice will establish your eligibility for the warranty. We will, at our option, replace or repair the part free of charge.

This warranty does not apply to normal wear and tear.

Wear and tear parts are identified as:

Scratches
Surface damages
Hardware and seals
Bearings
Corrosion
Stripped threads/bolts
Hinges